



6769

114°00′

5175 A TO

on appropriate requencies for that class B Airspace.

No person may take off or land a civil aircraft at an airport within the Class B Airspace or civil aircraft within the Class B Airspace uniess:

(a) The pilot in command holds at least a private pilot certificate or:

(b) The aircraft is operated by a student pilot who has met the requirements of FAR 61.1

. An operable VOR or TACAN receiver for IFR operations

JEAN (Ø



90 80

HENDERSON EXECUTIVE ADVISORY

All VFR aircraft departing Henderson Executive (HND) Runways 35 on a left downwind departure:
Use extreme caution due to high volume jet traffic arriving & departing McCarran Intl (LAS) west of HND. Pilots should remain within 1NM of HND when executing a left downwind departure, then continuing southbound

executing a left downwind departure, then continuing sour ining clear of the Las Vegas Class B. Aircraft departing via the northwest corridor to North Las Vegas (VGT): In addition to remaining clear of the Las Vegas Class B, remain below 3500' until clear of the HND Class D.